

Side Rail	Cross Brace	
	48"	
	SECTION 3648 \$76.35	36"

Side Rail	Cross Brace	
	48"	
	SECTION 3048 \$65.10	30"

Side Rail	Cross Brace	
	48"	
	SECTION 2448 \$57.55	24"

Side Rail	Cross Brace	
	SECTION 3636 \$67.75	36"

Side Rail	Cross Brace	
	SECTION 3036 \$56.55	30"

Side Rail	Cross Brace	
	SECTION 2436 \$48.75	24"

Side Rail	Cross Brace	
	SECTION 3630 \$67.75	36"

Side Rail	Cross Brace	
	SECTION 3030 \$56.55	30"

Side Rail	Cross Brace	
	SECTION 2430 \$48.75	24"

Side Rail	Cross Brace	
	SECTION 3624 \$55.95	36"

Side Rail	Cross Brace	
	SECTION 3024 \$45.45	30"

Side Rail	Cross Brace	
	SECTION 2424 \$38.65	24"

Side Rail	Cross Brace	
	SECTION 3616 \$43.10	36"

Side Rail	Cross Brace	
	SECTION 3016 \$34.25	30"

Side Rail	Cross Brace	
	SECTION 2416 \$29.00	24"

Scale: 3/4" on the drawing = 1 foot
All dimensions are 'outside' measurements

Leg Assembly Units should be spaced every 3 feet in your layout.

Template A



BENCHWORK

986 Jackson Harbor Road • Washington Island, WI 54246 • Phone (920) 847-2264