

Side Rail	Cross Brace	SECTION 2048 \$52.70	20"
	48"		

Side Rail	Cross Brace	SECTION 1848 \$49.90	18"
	48"		

Side Rail	Cross Brace	SECTION 1648 \$47.25	16"
	48"		

Side Rail	Cross Brace	SECTION 1248 \$41.60	12"
	48"		

Side Rail	Cross Brace	SECTION 2036 \$45.25	20"
	36"		

Side Rail	Cross Brace	SECTION 1836 \$42.45	18"
	36"		

Side Rail	Cross Brace	SECTION 1636 \$40.00	16"
	36"		

Side Rail	Cross Brace	SECTION 1236 \$35.60	12"
	36"		

Side Rail	Cross Brace	SECTION 2030 \$45.25	20"
	30"		

Side Rail	Cross Brace	SECTION 1830 \$42.45	18"
	30"		

Side Rail	Cross Brace	SECTION 1630 \$40.00	16"
	30"		

Side Rail	Cross Brace	SECTION 1230 \$35.60	12"
	30"		

Side Rail	Cross Brace	SECTION 2024 \$35.60	20"
	24"		

Side Rail	Cross Brace	SECTION 1824 \$33.60	18"
	24"		

Side Rail	Cross Brace	SECTION 1624 \$31.10	16"
	24"		

Side Rail	Cross Brace	SECTION 1224 \$27.20	12"
	24"		

Side Rail	Cross Brace	SECTION 2016 \$26.85	20"
	16"		

Side Rail	Cross Brace	SECTION 1816 \$25.40	18"
	16"		

Side Rail	Cross Brace	SECTION 1616 \$23.35	16"
	16"		

Side Rail	Cross Brace	SECTION 1216 \$18.10	12"
	16"		

Leg Assembly Units should be spaced every 3 feet in your layout.  
 Scale: 3/4" on the drawing = 1 foot  
 All dimensions are 'outside' measurements

Template B



**BENCHWORK**

986 Jackson Harbor Road • Washington Island, WI 54246 • Phone (920) 847-2264